

## Impact Sockets Pro Torque®, hexagon

Quick-Finder

Sockets

Quick-Finder

mm	12.5 □ 1/2		20 □ 3/4		25 □ 1	
	short	long	short	long	short	long
8		7248				
10	5210	7210				
11	5211	7211				
12	5212	7212				
13	5213	7213				
14	5214	7214				
15	5215	7215				
16	5216	7216				
17	5217	7217	5617	5717		5500-17
18	5218	7218	5618	5718		
19	5219	7219	5619	5719		5500-19
21	5221	7221	5621	5721		5500-21
22	5222	7222	5622	5722		
24	5224	7224	5624	5724		5500-24
26			5626	5726		
27	5227	7227	5627	5727	5827	5500-27
30	5230	7230	5630	5730	5830	5500-30
32	5232	7232	5632	5732	5832	5500-32
33			5633	5733	5833	5500-33
34			5634	5734	5834	
35			5635		5835	
36		7236	5636	5736	5836	5500-36
38			5638	5738	5838	5500-38
41	5233		5641	5741	5841	5500-41
46			5646	5746	5846	5500-46
50			5650	5750	5850	5500-50
55			5655	5755	5855	5500-55
56					5856	
60			5660	5760	5860	5500-60
65					5865	5500-65
70					5870	
75					5875	
80					5880	5500-80
85					5885	5500-85
90					5890	5500-90
95					5895	5500-95
100						5500-100
105					5905	5500-105
110					5910	5500-110
115					5915	5500-115
120					5920	



## Impact Sockets E-Type

mm	12.5 □ 1/2	20 □ 3/4
	long	long
E4		
E5		
E6		
E7		
E8		
E10	5204-10	
E11	5204-11	
E12	5204-12	
E14	5204-14	
E16	5204-16	
E18	5204-18	5347
E20	5204-20	5348
E22	5204-22	
E24	5204-24	5349
E26		5250-E26
E28		5250-E28
E30		5250-E30

