

1 DMM7
DIGITAL MULTIMETER

Measures AC/DC voltage, DC current and resistance. 16 position rotary function and range selector. Supplied with test probes and rubber bump cover and 12V battery.

Stock No.	Description
52320	Multimeter
53549	Crocodile Clips
53548	Probe Set



2 AMM1
POCKET ANALOGUE MULTIMETER

IEC61010 Specifications

- Measures AC/DC voltage, DC current and resistance
- 16 position rotary function and range selector
- Supplied with test probes

Features:

- Measures AC and DC Voltage
- Measures DC current • Measures resistance
- 16 position rotary function and range selector
- Recessed input terminals
- Test probes and lead included • Battery check facility

DC voltage	2.5, 10, 50, 250, 500V (acc. ±5% of full scale)
AC voltage	10, 50, 250, 500V (acc. ±5% of full scale)
DC current	500uA, 10mA, 250m (acc. ±5% of full scale)
Resistance	x10, x1K (acc. ±5%)
Size	64 x 100 x 35mm
Battery	1 x AA (not supplied)

Stock No.	Description
37317	Multimeter
51346	Crocodile Clips
37470	Probe Set
61834	Batteries (4 x AA)



3 BBFC1
BATTERY, BULB, FUSE AND CONTINUITY TESTER

Multi-purpose tester for dry cell 1.5V batteries (AAA, AA, C, D and button-type), 9V batteries (PP3 /6LR61), household and automotive fuses, bulbs (with bayonet fitting and push/screw type torch light bulbs). Readings show up on clear scale. There is also an audible continuity tester via test probes supplied. Size 70 x 145mm. Runs off 1 x 9V PP3/6LR61 battery (supplied). Display packed.

Stock No.	Description
57574	Tester
61837	Battery (PP3)



4 VT2
AC/DC VOLTAGE TESTER

Expert Quality, twin LED indicators identify voltage between 12-600V. Suitable for testing a host of wiring around the home or workplace, vehicle circuitry and electronic equipment etc. Probes fitted to 825mm of VDE approved cable. Display packed.

Stock No.
51957

5 BT1D
BATTERY TESTER

Handy battery tester suitable for AAA, AA, C, D, PP3 and button cell batteries. Display packed.

Stock No.
64514



6 ST-1
13A SOCKET TESTER

Expert Quality, for testing 13A sockets and RCD's rated less than 30mA. Detects the following electrical faults on sockets: true earth error (through LCD); no earth; L and N reverse; L and E reverse; E live; E open; N open and L open. Display packed.

Stock No.
22278



7 ST-2
13A SOCKET TESTER

For testing 13A sockets for the following faults: no Earth; L and N reverse; L and E reverse; Neutral fault and Live fault. Display packed.

Stock No.
34279

