

# PULLERS



995



996



999A



PO10A

## 1 Ton Capacity, Adjustable Jaw Puller

| Part No. | Description | Reach max. | Spread max. | Screw Size            | Weight  |
|----------|-------------|------------|-------------|-----------------------|---------|
| 995      | 2 Jaw       | 2 1/8"     | 3 1/4"      | 5/16"-24 x 3 7/8" lg. | 0.3 lb. |
| 996      | 3 Jaw       | 2 1/8"     | 3 1/4"      | 5/16"-24 x 3 7/8" lg. | 0.5 lb. |

## 2 Ton Capacity, Adjustable & Reversible Jaw Puller

| Part No. | Description | Reach max. | Spread max. | Screw Size           | Weight   |
|----------|-------------|------------|-------------|----------------------|----------|
| 999A     | 2 Jaw       | 3 3/8"     | 4"          | 3/8"-24 x 4 7/8" lg. | 0.9 lb.  |
| PO10A    | 3 Jaw       | 3 3/8"     | 4 3/4"      | 3/8"-24 x 4 7/8" lg. | 1.3 lbs. |



1001



PO11

## 5 Ton Capacity, Reversible Jaw Puller

| Part No. | Description | Reach max. | Spread max. | Screw Size              | Weight   |
|----------|-------------|------------|-------------|-------------------------|----------|
| 1001     | 2 Jaw       | 3 1/4"     | 6"          | 9/16"-20 x 6 15/16" lg. | 1.8 lbs. |
| PO11     | 2/3 Jaw     | 3 1/4"     | 7"          | 9/16"-20 x 6 15/16" lg. | 2.8 lbs. |



999LA



PO13A

## 5 Ton Capacity, Adjustable & Reversible Jaw Puller

| Part No. | Description | Reach max. | Spread max. | Screw Size              | Weight   |
|----------|-------------|------------|-------------|-------------------------|----------|
| 999LA    | 2 Jaw       | 5 1/2"     | 6"          | 9/16"-20 x 6 15/16" lg. | 2 lbs.   |
| PO13A    | 2/3 Jaw     | 5 1/2"     | 7"          | 9/16"-20 x 6 15/16" lg. | 3.5 lbs. |



### CAUTION

- Be sure puller is aligned & jaws are fully seated on part to be pulled.
- Do not modify or heat puller parts; this causes loss of strength and voids the product warranty.
- When possible use a larger sized puller to avoid potential overloading.